

FAULT	STEPS	PROCEDURE	GO TO STEP
NO READING ON GAUGE	1	TURN OFF PUMP	2
	2	TURN CHLORONATOR SWITCH TO OFF POSITION	3
	3	PRESS RESET BUTTON (BELOW SWITCH)	4
	4	ENSURE CELL AND SENSOR PIN CLEAN CLEAN CELL IN 1 PART ACID TO 10 PART WATER CLEAN SENSOR PIN OF ANY WHITE BUILD UP	5
	5	ONLY SWITCH PUMP ON	6
	6	ENSURE CELL HOUSING IS COMPLETELY FULL OF WATER IF AIR POCKET UNDER LID UNSCREW LID SLIGHTLY TO REMOVE AIR POCKET SENSOR PIN MUST BE COVERED BY WATER	7
	7	TURN CHLORINATOR SWITCH TO SETTING 3 IF SALT LEVEL IS CORRECT GAUGE WILL READ 75% IF READING LOWER THAN 75% ADD SALT	
STILL NO READING		CHECK CONNECTIONS ON CELL ARE CLEAN AND TIGHT IF SALT LEVEL IS CORRECT GAUGE WILL READ 75% IF READING LOWER THAN 75% ADD SALT	
STILL NO READING		POWER PACK AND CELL TO BE SENT/BROUGHT IN FOR EVALUATION AND REPAIR	
GAUGE FLICKERS		ENSURE CELL HOUSING IS COMPLETELY FULL OF WATER BACKWASH FILTER & CHECK FOR SUCTION LEAK	
LOW READING ON GAUGE		ENSURE CELL AND SENSOR PIN ARE CLEAN HAVE SALT LEVEL TESTED AND ADD AS REQUIRED	
STILL LOW READING		CELL MAY BE DAMAGED POWER PACK AND CELL TO BE SENT/BROUGHT IN FOR EVALUATION AND REPAIR	
FUSE KEEPS BLOWING		POWER PACK AND CELL TO BE SENT/BROUGHT IN FOR EVALUATION AND REPAIR	
RESET BUTTON KEEPS POPPING OUT		POWER PACK AND CELL TO BE SENT/BROUGHT IN FOR EVALUATION AND REPAIR	
NO CHLORINE TESTED IN POOL WATER UNIT WORKING CORRECTLY		TEST WATER FOR STABILIZER (60PPM) TEST WATER FOR TOTAL DISSOLVED SOLIDS WATER MAY NEED TO BE REFRESHED	
IF IN DOUBT		CALL THE JUSTCHLOR AGENT KZN 031 701 4722 - SCOTTY - smanickum@jasco.co.za JHB 011 900 1637 - RUDY - sales@technospa.co.za CT 021 706 7575 - GRAHAM - justsalt@wbs.co.za	